

## **INSTRUCTIONS FOR FITTING A PIPE TO UNDERGROUND WATER TANKS**

1. Drill out the hole for the pipe using a 108mm hole cutting saw.
2. Cut the 110mm pipe square, using a fine tooth saw.
3. Chamfer the end of the pipe, using a medium file or rasp.
4. Remove dust and filings from the end of the pipe
5. Push the pipe into the hole drilled in the tank. The end of the pipe can be lubricated.
6. Seal the outside joint using CT1.